

## Programs DWC5906 &amp; DWC5916

PROGRAM	DESCRIPTION	TEMPERATURE*	ENERGY (kWh) HOT / COLD	WATER (L)	TIME (min) HOT / COLD
Sani A	Programme for effectively cleaning particularly dirty dishes. The temperature of the main wash is 60°C. The final rinse is 85°C for 6 minutes.	60°C / 85°C	DWC5906: 1.3 / 1.9 DWC5916: 1.3 / 1.9	DWC5906: 14 DWC5916: 14	DWC5906: 80 / 95 DWC5916: 80 / 95
Sani B	Programme for effectively cleaning particularly dirty dishes. The temperature of the main wash is 50°C. The final rinse is 85°C for 10 minutes.	50°C / 85°C	DWC5906: 1.3 / 1.9 DWC5916: 1.3 / 1.9	DWC5906: 10 DWC5916: 10	DWC5906: 40 / 60 DWC5916: 40 / 60
Heavy	Programme for very dirty dishes, such as pans, casserole dishes and oven dishes. If these dishes do not completely fill the dishwasher, you can add plates and the like.	60°C / 65°C	DWC5906: 1.0 / 1.5 DWC5916: 1.0 / 1.5	DWC5906: 19 DWC5916: 19	DWC5906: 180 / 195 DWC5916: 180 / 195
Normal	Use to wash normal dirty dishes, and even dishes with dried leftovers, including plates, serving dishes, cups, glasses and so on.	60°C / 65°C	DWC5906: 0.8 / 1.5 DWC5916: 0.8 / 1.5	DWC5906: 18 DWC5916: 18	DWC5906: 145 / 170 DWC5916: 145 / 170
Daily	A programme suitable for day-to-day dishwashing. This programme can also clean dried leftovers, but is not intended for burnt food, such as on oven dishes.	60°C / 65°C	DWC5906: 0.7 / 1.3 DWC5916: 0.7 / 1.3	DWC5906: 13 DWC5916: 13	DWC5906: 130 / 145 DWC5916: 130 / 145
Quick	This programme is used for glasses and porcelain that is slightly dirty, such as coffee cups.	30°C / 30°C	DWC5906: 0.1 / 0.2 DWC5916: 0.1 / 0.2	DWC5906: 10 DWC5916: 10	DWC5906: 20 / 20 DWC5916: 20 / 20
Delicate	If the dishes are not very dirty, you can select Delicate wash. This programme is intended for glasses and porcelain that have just been used and as such do not require such a powerful programme.	40°C / 50°C	DWC5906: 0.5 / 0.9 DWC5916: 0.5 / 0.9	DWC5906: 15 DWC5916: 14	DWC5906: 95 / 110 DWC5916: 95 / 110
Eco	Use when you want to save energy. For normal dirty dishes.	55°C / 55°C	DWC5906: 0.8 / 1.04 DWC5916: 0.8 / 1.04	DWC5906: 10.7 DWC5916: 9.45	DWC5906: 170 / 185 DWC5916: 210 / 225
Rinse & Hold	Used to rinse dishes while you wait for the dishwasher to become fully loaded.	- / -	DWC5906: 0.01 / 0.01 DWC5916: 0.01 / 0.01	DWC5906: 3 DWC5916: 3	DWC5906: 6 / 6 DWC5916: 6 / 6

Values in table above have been tested with 65°C hot or 15°C cold water connection with a D5906 (XL) dishwasher

\* Main wash / final rinse

## Programs DWC5926

PROGRAM	DESCRIPTION	TEMPERATURE*	ENERGY (KWH) HOT / COLD	WATER (L)	TIME (MIN) HOT / COLD
Quick wash	This programme is used for glasses and porcelain that is slightly soiled, such as coffee cups.	60°C / 65°C	0.7 / 1,3	14	10 / 20
Universal	Standard program for normally soiled dishes.	60°C / 70°C	0.8 / 1.5	14	25 / 25
Universal plus	Cleaning of heavily soiled dishes where a major part of the soiling can be removed using cold water prewash.	65°C / 70°C	0.9 / 1,7	17	40 / 40
Intensive	A programme suitable for day-to-day dishwashing. This programme can also clean dried leftovers, but is not intended for burnt food, such as on oven dishes.	65°C / 70°C	1,0 / 2,1	22	60 / 60
Wine glasses	Delicate wash at low pressure. This programme is intended for glasses and porcelain that have just been used.	55°C / 50°C	0.4 / 1,0	14	20 / 20
Beer glasses	Adopted for more robust and thicker beer glasses. Cold water in final rinse.	55°C / -	0.4 / 0.7	14	15 / 20
Plastic	Program adapted for plastic items that can withstand dishwashing cycle. Also for porcelain and glasses.	60°C / 60°C	0.7 / 1,4	17	40 / 40
Pots & pans	Programme for very dirty dishes, such as pans, casserole dishes and oven dishes. If these dishes do not completely fill the dishwasher, you can add plates and the like.	70°C / 70°C	1,1 / 1.5	23	160 / 180
ECO	Use to wash normal dirty dishes, and even dishes with dried leftovers, including plates, serving dishes, cups, glasses and so on.	55°C / 45°C	0.7 / 1.0	17	165 / 180
Universal Sani	Programme for effectively cleaning particularly dirty dishes. The temperature of the main wash is 60°C. The final rinse is 85°C for 3 minutes.	60°C / 85°C	1,3 / 2,0	17	40 / 45
Quick wash Sani	Programme for effectively cleaning particularly dirty dishes. The temperature of the main wash is 60°C. The final rinse is 85°C for 3 minutes.	60°C / 85°C	1.2 / 1.9	14	20 / 30
Rinse	Used to rinse dishes while you wait for the dishwasher to become fully loaded.	- / -	0.01 / 0.01	5	3 / 3
Drain	Pumping out water, for example in the event of programmes being interrupted.	- / -	0.01 / 0.01	-	2 / 2

Values in table above have been tested with 65°C hot or 15°C cold water connection with a DWC5926 (XL) dishwasher

\* Main wash / final rinse

PROGRAM	DESCRIPTION	TEMPERATURE*	ENERGY (KWH) HOT / COLD	WATER (L)	TIME (MIN) HOT / COLD
Quick wash	This programme is used for glasses and porcelain that is slightly soiled, such as coffee cups.	60°C / 82°C	0,8 / 1,2	8	5 / 10
Quick wash universal	For normally soiled dishes. Used for glasses and porcelain and coffee cups.	60°C / 82°C	0,8 / 1,3	12	15 / 20
Universal	Standard program for normally soiled dishes.	60°C / 82°C	0,9 / 1,4	12	15 / 20
Universal plus	Cleaning of heavily soiled dishes where a major part of the soiling can be removed using cold water prewash.	60°C / 82°C	0,9 / 1,5	15	20 / 25
Intensive	A programme suitable for day-to-day dishwashing. This programme can also clean dried leftovers, but is not intended for burnt food, such as on oven dishes.	65°C / 82°C	1,2 / 2,0	18	60 / 60
Wine glasses	Delicate wash at low pressure. This programme is intended for glasses and porcelain that have just been used.	55°C / 50°C	0,3 / 0,8	12	15 / 15
Beer glasses	Adopted for more robust and thicker beer glasses. Cold water in final rinse.	55°C / -	0,3 / 0,5	12	10 / 15
Rinse	Used to rinse dishes while you wait for the dishwasher to become fully loaded.	- / -	0,01 / 0,01	5	2 / 2
Drain	Pumping out water, for example in the event of programmes being interrupted.	- / -	0,01 / 0,01	-	2 / 2
Program A	Programs which can be adapted for specific needs.	-	-	-	-
Program B	Programs which can be adapted for specific needs.	-	-	-	-
Program C	Programs which can be adapted for specific needs.	-	-	-	-

Values in table above have been tested with 65°C hot or 15°C cold water connection with a DWC5936 (XL) dishwasher

\* Main wash / final rinse